


How To Add Temp And Humidity From SCD40

1. Navigate to the ESPHome addon
2. Select the Edit button under the desired device

[ESPHome Edit Button.png](#)

3. Insert your code (The example below is for our AIR-1 SEN55 sensor but this applies to MSR-1/2, MTR or any sensor with the CO2 module)

```
sensor:
  - platform: scd4x
    id: !extend scd40
  temperature:
    name: "SCD40 Temperature"
  humidity:
    name: "SCD40 Humidity"
```



4. In the top right of the same screen Select Save and then Install

5. If it compiles correctly then you should see a green Success

[Install Success.png](#)
Image not found, type unknown

6. When you see the sensor logs, you are finished and can select Stop

[Sensor Log Stop.png](#)
Image not found, type unknown

7. Now your sensor value should update!

Revision #1

Created 21 May 2024 00:53:28 by Trevor

Updated 21 May 2024 00:55:58 by Trevor