Removing Device From Home Assistant

This will cover how to remove an Apollo device from Home Assistant

1. Navigate to Home Assistant and open your ESPHome addon

image.png
Image not found or type unknown

2. On the device you would like to remove, click the three dots and select "Delete"

image.png
Image not found or type unknown

3. Go to Settings --> Devices & Services --> ESPHome

image.png
Image not found or type unknown

4. On the device you would like to remove, click the three dots and then "Delete"

image.png
Image not found or type unknown

5. Restart your Home Assistant

image.png
Image not found or type unknown

It can take a few minutes for your Home Assistant instance to start back up

Revision #3
Created 1 November 2023 16:23:54 by Trevor
Updated 5 December 2023 04:30:34 by Trevor