

Removing Device From Home Assistant

This will cover how to remove an Apollo device from Home Assistant


1. Navigate to Home Assistant and open your ESPHome add-on

 image.png and or type unknown


2. On the device you would like to remove, click the three dots and select "Delete"

 image.png and or type unknown


3. Go to Settings --> Devices & Services --> ESPHome

 image.png and or type unknown

4. On the device you would like to remove, click the three dots and then "Delete"

 image.png and or type unknown

5. Restart your Home Assistant

 image.png and or type unknown

It can take a few minutes for your Home Assistant instance to start back up

Revision #3

Created 1 November 2023 16:23:54 by Trevor

Updated 5 December 2023 04:30:34 by Trevor