

Updating Firmware

Updating Through ESPHome Addon

1. In HomeAssistant open the [ESPHome addon](#)
2. Or click this to [Open your Home Assistant instance and show the dashboard of the ESPHome add-on.](#)
3. Make sure you are running the latest version of ESPHome
4. On older hardware, it will not auto-update so you will have to uninstall and reinstall ESPHome
5. Find the sensor you want to update and click the three dots in the bottom right

[Firmware1.png](#)
Image not found, type unknown

5. Select “Validate” from the list

[Firmware2.png](#)
Image not found, type unknown

6. Once the validation completes, click “Install” in the bottom right

[Firmware3.png](#)
Image not found, type unknown

7. Complete!

Revision #6

Created 5 December 2023 04:53:35 by Trevor

Updated 5 June 2024 20:47:24 by SmartHomeSellout