

Teardown and Reassembly of the MSR-2

This will cover how to take apart and reassemble the MSR-2 device. This is useful if you are replacing components or to inspect if the mmwave sensor (LD2410B) is seated properly. Sometimes during shipping, this can become loose and cause issues with the accuracy of the sensor.

<https://www.youtube.com/watch?v=hkNrkJuMmxI>

Revision #12

Created 17 August 2024 14:16:49 by SmartHomeSellout

Updated 17 August 2024 14:21:32 by SmartHomeSellout