

# Teardown and Reassembly of the MTR-1

This will cover how to take apart and reassemble the MTR-1 device. This is useful if you are replacing components or to inspect if the mmwave sensor (LD2450) is seated properly. Sometimes during shipping, this can become loose and cause issues with the accuracy of the sensor

<https://www.youtube.com/embed/r2YhuNolZw4>

---

Revision #3

Created 20 June 2024 23:14:57 by SmartHomeSellout

Updated 20 June 2024 23:22:13 by SmartHomeSellout